

# DRY APPLICATION OF DECALS USING TOP HINGE METHOD

Prior to commencement ensure surface is cleaned  
with white spirit and thoroughly dry



Suggested Position



Step 1 : Fix 2 x small pieces of masking  
tape to the top corners of the decal.  
Slide into required position and hold  
with tape.



Step 2 : Apply a strip of masking tape  
along the top edge, half on the decal  
and half on the panel.



Step 3 : Fold backwards, hinging on the  
masking tape, and carefully peel back  
the backing paper. Apply ensure all the  
vinyl remains in contact with the clear  
transfer tape as the backing paper is  
peeled off.



Step 4 : Fold forwards carefully, allow  
the top section to contact the panel  
first, work from the centre across, then  
downwards with your finger or a  
squeegee to ensure any bubbles or  
creases are removed.



Step 5 : Application completed. Apply  
pressure all over the decal to ensure  
permanent contact with the panel.



Carefully peel back masking and  
transfer tape, ensuring that none of the  
decals is removed.